

USER MANUAL


Most chicken eggs can be tested for fertility on the SureView Egg Fertility Tester in 3 simple steps.

Fertility testing can be done **after eggs have been incubating the incubator for 10 days.** You can also repeat the process on **Day 18** before you take the eggs to the hatcher.

Do the following steps as fast as possible - don't keep the eggs out of the incubator for too long or you will cause damage to the eggs. **The eggs must not be outside the incubator for more than 5 minutes.**

STEP 1: In a DARK ROOM

Switch the SureView Candler **ON** and take a **full tray of 30 chicken eggs** and place on the SureView. Make sure you place the tray correctly so that the light shine below each egg. **The room must be DARK** (The SureView will not work properly if the room is too light)



STEP 2:

Check which eggs are fertile and which are not-fertile. This will show instantly on the SureView

FERTILE EGGS will have a **DARK MASS** inside of them. **NOT-FERTILE EGGS** will be **CLEAR/TRANSPARENT** and the light will shine easily through them.

REMOVE the not-fertile eggs and **throw them away** — they will never hatch.

The picture below shows fertile eggs (Green Ticks) and not-fertile eggs (Red Crosses)



STEP 3:

Place the **FERTILE EGGS** immediately back into the incubator/hatcher and repeat Steps 1, 2 and 3.

Don't let the eggs cool down too much outside the incubator!